

Mont Blanc 3000

# Flexikit 3



785999 BU2 Foot unit



786120 FK120 Fitting kit



774251 T126 Steel load bar



776261 A126 Alu load bar



Inkl Lock included

Close x

x Close

 More information

READY FIT

Read more >>



## Which roof rack fits your car?

Choose car make and model from the list below

LANDROVER

Discovery 3 SUV 10-04-

OK