

## Items Required

14mm Hex Key  
10mm Socket  
Circlip Pliers  
Jack  
Axle stands  
Extendable Magnet  
Locking Wheel nut  
New Circlip

## Steps required

Step 1 - Raise and support the Vehicle on axles stands

Step 2 - Remove Gearbox under tray - using 10mm Socket

Step 3 - Remove drivers side front wheel



Step 4 - Locate Hex plug on the Gear Box

Step 5 - Remove Hex using 14mm Allen Key

Step 7 - Remove spring using magnet



## ‘ How to Guide ‘

---

Step 8 - Remove broken parts of Circlip (if broken)

Step 9 - Remove tube with Circlip

Step 10 - Replace Circlip

Step 11 - Replace tube into gear box.



Step 12 - Insert Spring



Step 13 - Locate hex plug and tighten

Step 14 - Test Gear Stick selection

Step 15 - Secure gear box under tray.

Step 16 - Refit Wheel

Step 17 - Lower to Ground

Step 18 - Torque Wheels to 140NM