



LAND ROVER LR3 INSTALLATION



**TRIM SHROUD IN THIS AREA SO IT
OVERLAPS THE FACTORY
DOMELIGHT/AC CONTROL PANEL**

INSTALLATION TIPS

- INSTALLATION REQUIRES SLIGHT TRIMMING TO THE STANDARD A7 INSTALLATION SHROUD.
 - USE A CONTOUR GAUGE TO CREATE AN EXACT TRIM TEMPLATE
 - REMOVE SHROUD FROM THE A7 PRIOR TO TRIMMING
 - MARK CUT LINE ON SHROUD AND CAREFULLY CUT
 - SAND CUT EDGE AND DRYFIT TO THE VEHICLE
 - TO REALLY MAKE YOUR INSTALLATION MORE PROFESSIONAL LOOKING, AND TO ELIMINATE ANY GAPS THAT MAY OCCUR, GLUE & WRAP THE TRIMMED SHROUD WITH FACTORY MATCHING HEADLINER MATERIAL
- THE A7 INSTALLATION BRACKET WILL EASILY ATTACH TO THE FLAT AREA LOCATED BEHIND THE FRONT SUNROOF. THIS AREA IS VERY RIGID AND SUPPORTS THE A7 EXTREMELY WELL.