Mr./Mrs./Ms.:	Model:	Reg. No.: CIO DSC.	
Invoice/Job No.:	Odometer Reading:		

В

Α

В



DISCOVERY 3 (ALL MODELS UK & EU) MAINTENANCE CHECK SHEE

Months 12 24 36 48 60 72 84 96 108 120 105 miles: 15 30 45 60 75 90 105 120 135 150

Adjust/Lubricate/Replace - Labour cost included in scheduled time except items marked *

Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and replaced to extra l

Sheck - After th	e checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and mate	terial cos	Sτ.	MAINTENANCE CHECK SHEET
A (B MAIN SERVICE (VEHICLE INTERIOR)		Α	B MAIN SERVICE (UNDER VEHICLE) Check visually brake servo hose, brake, fuel, PAS and clutch pipes, unions,
	Check condition and security of seats and seatbelts Check operation of all lamps, horns and warning indicators	36.		and electrical harnesses for chafing, leaks and corrosion
	— Check operation of all lamps, norms and warning indicators — Check operation of front/rear wipers and washers and condition of wiper	37.		Check the adjustment of the electric park brake
3	— blades	38. 39.		Check for fluid leaks
1.	Select the LOW range gears and drive the vehicle 3 to 4 vehicle lengths then	39. 40.		Check exhaust system for leaks, security and damage Check torque of tie rod end nuts. Tighten to 76Nm if necessary
5 — —	── re-select HIGH range gears ☐─ Replace pollen filter	41.		Check steering rod ball joint fixings and condition of ball joints and dust covers
	MAIN SERVICE (VEHICLE EXTERIOR)	42.		If fault lamp(s) are illuminated, interrogate that system using T4/IDS and report
	— Annual corrosion/cosmetic inspection - Using annual corrosion inspection	43.		☐ ☐ findings* ☐ ☐ Carry out road test <i>(see WARNING over page)</i>
3.	sheet	44.		Reset service interval announcement indicator
7.	Check tyre pressures, condition and tread depth.	45.		Endorse service record
	Remove road wheels	46. 47.		Check for any applicable outstanding service actions or recalls Report any unusual features of vehicle condition and additional work required
	Inspect brake pads for wear, calipers for leaks and disks for condition	47.		Teport any unusual leatures of vehicle condition and additional work required
10.	Replace Brake Fluid (Every 3 years)*			
1.	Renew fuel filter element (Diesel) Drain fuel sedimentor (Diesel)			
12.	Refit road wheels to opposite sides of the same axle (Use anti-sieze			
13.	── compound on spigot bore) Not vehicles fitted with uni-directional tyres			
14.	Check operation of door checks, bonnet catch & fuel flap and lubricate door checks			
15.	Apply lubricant to door seals - Russian and Nordic markets only			
	MAIN SERVICE (UNDER BONNET)			
l6. 🔲 🗆	Check anti-freeze specific gravity			
17.	Renew coolant (Every 10 years)			
8. 105k	Renew spark plugs			
19. <u>[6</u> 20. <u>45k</u> [9	Ok Renew air cleaner element (Petrol) Ok Renew air cleaner element (Diesel)			
21.	Check condition of ancillary driving belts			
22.	Renew ancillary driving belts (Petrol)			
	Renew ancillary driving belts (<i>Diesel</i>) Renew front and rear camshaft timing belts, tensioners and tensioner bolt		100	
24. 105k	(Diesel)			
25.	Check/top up brake, PAS and clutch fluid levels and screen washer reservoirs			
26 27	Check/top up battery electrolyte level <i>low maintenance battery fitted</i> Renew engine oil and filter			
	B MAIN SERVICE (UNDER VEHICLE)			
	Renew manual gearbox oil <i>(Every 10 years)</i>			enance items listed, are those recommended for vehicles operating under normal driving, it is it is subject to
29.	Renew automatic transmission oil and filter (Every 10 years)			operation, extremes of temperature, dusty conditions, off road driving or frequent towing
30. 75k 19	Renew transfer box oil, replace drain and fill plug washers	of tra	ailers.	
31 [32. 75k 15	Renew front and rear axle oil (Every 10 years) Renew locking differential oil	Servi		eck completed, cosmetic/corrosion inspection check completed and service portfolio book
33. [/5K] [18	Check for free play in all suspension and body mounting rubbers	endo	nseu.	
84.	Check condition of all suspension, driveshafts and steering boots and gaiters	Name	Α.	Date:
35	Replace all flexible brake hoses (Every 6 years)*	Haiil		Date

В

Service type: